CALIBRATION & WARRANTY

- Obtain Warranty online: tramexmeters.com/register
- Annual calibrations are recommended as best practice. Calibration Check Boxes can be purchased for regular checks.

TROUBLESHOOTING

- All LEDs flashing when unit is powered up.
 - Batteries are low and will soon need to be replaced.
- Single LED flashing and meter frozen.
 - Moisture Encounter is in HOLD mode.
 - Press HOLD button to release.

USER GUIDE ONLINE

Please use the following link or QR code to access the complete User Guide online: http://l.ead.me/bb3OyA



Free App Available for Mobile and Tablet:





LI-ME5QSGUS



MOISTURE ENCOUNTER





QUICK START GUIDE

OPERATION

- Press () to switch ON/OFF.
- Press to select the required mode/scale.
- Press Moisture Encounter fully against the surface of the material.
- Readings are instant and dispayed on analog dial.



- Last scale used is memorized when power is shut down and automatically selected next time unit is powered up.
- Hold/freeze: Press ® once. In HOLD mode the Hold LED will flash continuously. Press ® again to release hold. (If powered down while on Hold, the Moisture Encounter will retain information until powered up and hold is pressed again to release)
- Turn Audio signal on or off by pressing HOLD/ AUDIO twice in quick succession.
- Automatic power timeout (5 mins) conserves battery life.

SCALES

 Upper scale (5-30) indicates moisture content (MC%) of wood when used on wood products.



 Lower Scale (0-100) is a comparative scale and may be used for recording and comparing moisture condition in materials other than wood.

DUAL-DEPTH PENETRATION

- Shallow depth up to 0.40" (10mm)
- Deep depth up to 1.25" (30mm)

MATERIALS AND SCALE SELECTION

- The ME5 has 5 ranges of sensitivity:
 - Wood & Timber
 - Shallow Depth
 - · Drywall & Roofing
 - Plaster & Tile
 - Masonry

BLUETOOTH

Press ** to switch Bluetooth ON/OFF.
Readings will be sent to the Tramex App on your mobile device.